

Ostrzeżenia i informacje o bezpieczeństwie użytkowania oraz utylizacji

1. Montaż i instalacja:

- Montaż lampy powinien być wykonany przez osobę wykwalifikowaną, zgodnie z dołączoną instrukcją.
- Przed montażem upewnij się, że napięcie w instalacji elektrycznej odpowiada wartości podanej na produkcie.
- Upewnij się, że lampa jest stabilnie zamocowana lub ustawiona na równej powierzchni (jeśli dotyczy).
- W przypadku lamp o podwyższonym stopniu ochrony IP (np. IP44 lub wyższe), upewnij się, że wszystkie połączenia elektryczne są odpowiednio zabezpieczone przed wodą i wilgocią (jeśli dotyczy).

2. Bezpieczeństwo użytkowania

- Produkt przeznaczony do użytku wewnętrznego lub na zewnątrz w zależności od oznaczenia IP.
- Sprawdź specyfikację techniczną, aby upewnić się, że lampa posiada odpowiedni stopień IP.
- Lampy z oznaczeniem IP44 lub wyższym są odporne na zachlapanie wodą, ale nie powinny być zanurzane w wodzie, chyba że oznaczono inaczej (jeśli dotyczy).
- Przed wymianą źródła światła lub czyszczeniem zawsze odłącz lampę od zasilania.
- Nie przykrywaj lampy ani źródła światła, aby uniknąć przegrzania.
- Minimalna odległość od oświetlanych powierzchni wynosi 50 cm, chyba że instrukcja stanowi inaczej.

3. Funkcje dodatkowe (jeśli dotyczy)

- Piloty zdalnego sterowania oraz inne elementy elektroniczne należy przechowywać w suchym miejscu, z dala od dzieci oraz źródeł ciepła.
- Funkcja ściemniania lub zmiany barwy światła działa wyłącznie w kompatybilnych instalacjach elektrycznych.
- W przypadku produktów z bateriami w pilotach, zużyte baterie należy utylizować zgodnie z lokalnymi przepisami.

4. Konserwacja

- Regularnie sprawdzaj stan przewodów, wtyczek oraz obudowy lampy, aby upewnić się, że są w dobrym stanie technicznym.
- Przed czyszczeniem wyłącz zasilanie. Do czyszczenia używaj miękkiej, suchej ściereczki. Nie używaj agresywnych detergentów ani środków czyszczących mogących uszkodzić powierzchnię lampy.
- W przypadku lamp zewnętrznych regularnie kontroluj szczelność obudowy i usuwaj nagromadzony brud lub wodę, aby zapewnić długotrwałą ochronę przed czynnikami atmosferycznymi-Zawsze przy wyłączonym zasilaniu.
- Źródło światła powinno być wymienione zgodnie z zaleceniami producenta, używając żarówek lub modułów LED o odpowiedniej mocy i typie. Wymiana źródła światła powinna zawsze być wykonana przez wykwalifikowanego specjalistę.

5. Informacja o utylizacji (WEEE)

- Produkt oznaczony symbolem przekreślonego kosza nie może być wyrzucany z odpadami komunalnymi.
- Zużyte lampy, urządzenia elektryczne oraz źródła światła należy przekazać do odpowiedniego punktu zbiórki odpadów elektrycznych i elektronicznych.
- W przypadku lamp z wbudowanymi modułami LED, produkt należy utylizować w całości jako sprzęt elektryczny.

Warnings and Safety Information for Use and Disposal

1. Assembly and Installation:

The lamp should be installed by a qualified person in accordance with the included instructions. Before installation, ensure that the electrical installation voltage matches the value specified on the product.

Ensure that the lamp is securely mounted or placed on an even surface (if applicable).

For lamps with a higher IP protection rating (e.g., IP44 or higher), ensure that all electrical connections are adequately sealed against water and moisture (if applicable).

2. Safe Usage:

The product is intended for indoor or outdoor use, depending on the IP rating.

Check the technical specification to ensure the lamp has the appropriate IP rating.

Lamps with an IP44 rating or higher are resistant to water splashes but should not be submerged unless otherwise specified (if applicable).

Always disconnect the lamp from the power supply before replacing the light source or cleaning it.

Do not cover the lamp or light source to avoid overheating.

Maintain a minimum distance of 50 cm from illuminated surfaces unless otherwise specified in the manual.

3. Additional Features (if applicable):

Remote controls and other electronic components should be stored in a dry place, away from children and heat sources.

The dimming or color-changing function works only with compatible electrical installations.

For products with batteries in remotes, dispose of used batteries in accordance with local regulations.

4. Maintenance:

Regularly inspect the condition of cords, plugs, and the lamp housing to ensure they are in good technical condition.

Turn off the power before cleaning. Use a soft, dry cloth for cleaning. Do not use aggressive detergents or cleaning agents that may damage the lamp surface.

For outdoor lamps, periodically check the housing's seal and remove accumulated dirt or water to ensure long-term protection against weather conditions—always with the power turned off.

Replace the light source according to the manufacturer's recommendations, using bulbs or LED modules of the appropriate power and type. Light source replacement should always be performed by a qualified specialist.

Disposal Information (WEEE):

Products marked with a crossed-out bin symbol must not be disposed of with household waste.

Used lamps, electrical devices, and light sources should be taken to an appropriate collection point for electrical and electronic waste.

For lamps with built-in LED modules, the product must be disposed of in its entirety as electrical equipment.

